

AIRPORT DIAGRAM

[USAF] AFD-1422 (RAAF)

TOWNSVILLE (YBTL)
TOWNSVILLE, AUSTRALIA

ATIS
 276 114.1
 TOWNSVILLE TOWER ★
 118.3 257.8
 GND CON
 121.8 264.6
 CLNC DEL
 128.1 236.1
 123.4 ①

19° 14'S

RWY 01-19
 PCN 71 F/D/X/T
 RWY 07-25
 PCN 8 F/A/Z/U



MAY 2003

ANNUAL RATE OF CHANGE
 0.0°E

100 x 150

01

ELEV 13

BAK-12

7999 x 148

195.3°

19° 15'S

84 TWR

ELEV 14

25

ELEV 12

3609 x 98

253.9°

BAK-12

07

073.9°

FIELD ELEV 18

100 x 150

01

19° 16'S

146° 45'E

146° 46'E

AIRPORT DIAGRAM

WGS DATUM

TOWNSVILLE, AUSTRALIA
TOWNSVILLE (YBTL)

Effective 31 AUG 2006 - 28 SEP 2006